

OUTDOOR UNIT SERVICE MANUAL




No. OBH686

Models

MUZ-HE09NA
MUZ-HE12NA
MUZ-HE15NA
MUZ-HE18NA
MUZ-HE24NA

Indoor unit service manual
MSZ-HE•NA Series (OBH685)



MUZ-HE09NA
MUZ-HE12NA
MUZ-HE15NA

CONTENTS

1. TECHNICAL CHANGES	2
2. PART NAMES AND FUNCTIONS	3
3. SPECIFICATION	4
4. OUTLINES AND DIMENSIONS	7
5. WIRING DIAGRAM	10
6. REFRIGERANT SYSTEM DIAGRAM	13
7. DATA	16
8. ACTUATOR CONTROL	30
9. SERVICE FUNCTIONS	31
10. TROUBLESHOOTING	31
11. DISASSEMBLY INSTRUCTIONS	52

PARTS CATALOG (OBB686)

NOTE:

RoHS compliant products have <G> mark on the spec name plate.

Use the specified refrigerant only

Never use any refrigerant other than that specified.

Doing so may cause a burst, an explosion, or fire when the unit is being used, serviced, or disposed of.

Correct refrigerant is specified in the manuals and on the spec labels provided with our products.

We will not be held responsible for mechanical failure, system malfunction, unit breakdown or accidents caused by failure to follow the instructions.

1

TECHNICAL CHANGES

MUZ-HE09NA

MUZ-HE12NA


MUZ-HE15NA

MUZ-HE18NA


MUZ-HE24NA

1. New model


MUZ-HE09NA MUZ-HE12NA MUZ-HE15NA



MUZ-HE18NA



MUZ-HE24NA



Outdoor unit model			MUZ-HE09NA	MUZ-HE12NA	MUZ-HE15NA	MUZ-HE18NA
Capacity Rated (Minimum~Maximum)	Cooling ※1	Btu/h	9,000 (3,800 ~ 10,000)	12,000 (3,800 ~ 12,200)	14,000 (3,100 ~ 16,000)	17,200 (3,700 ~ 18,000)
	Heating 47 ※1	Btu/h	10,900 (4,500 ~ 11,800)	12,200 (5,500 ~ 14,500)	18,000 (4,800 ~ 18,500)	18,000 (3,500 ~ 20,900)
Power consumption Rated	Cooling ※1	W	750	1,210	1,170	1,640
	Heating 47 ※1	W	900	990	1,600	1,590
EER ※1 [SEER] ※2	Cooling		12.0 [18.0]	9.9 [18.0]	12.0 [18.0]	10.5 [18.0]
HSPF IV ※3	Heating		8.5			
COP	Heating ※1		3.55	3.61	3.30	3.32
Power supply	V , phase , Hz		208/230 , 1 , 60			
Max. fuse size (time delay)		A	15			
Min. circuit ampacity		A	12			14
Fan motor		F.L.A	0.50			0.93
Compressor	Model		KNB073FQDHC	KNB092FQAHC	SNB130FQBHT	
		R.L.A	6.6		7.4	10.0
		L.R.A	8.2		9.3	12.5
	Refrigeration oil (Model)	L	0.32 (NEO22)		0.45 (NEO22)	
Refrigerant control			Linear expansion valve			
Sound level ※1	Cooling	dB(A)	46	49		54
	Heating	dB(A)	50	51		56
Defrost method			Reverse cycle			
Dimensions	W	in.	31-1/2			33-1/16
	D	in.	11-1/4			13
	H	in.	21-5/8			33-7/16
Weight		lb.	66	77	80	119
External finish			Munsell 3Y 7.8/1.1			
Remote controller			Wireless type			
Control voltage (by built-in transformer)		VDC	12 - 24			
Refrigerant piping			Not supplied			
Refrigerant pipe size (Min. wall thickness)	Liquid	in.	1/4 (0.0315)			
	Gas	in.	3/8 (0.0315)		1/2 (0.0315)	
Connection method	Indoor		Flared			
	Outdoor		Flared			
Between the indoor & outdoor units	Height difference	ft.	40			50
	Piping length	ft.	65			100
Refrigerant charge (R410A)			1 lb. 12 oz.	2 lb. 9 oz.		3 lb. 7 oz.

NOTE: Test conditions are based on AHRI 210/240.

*1: Rating conditions (Cooling) — Indoor: 80°FDB, 67°FWB, Outdoor: 95°FDB, (75°FWB)
(Heating) — Indoor: 70°FDB, 60°FWB, Outdoor: 47°FDB, 43°FWB

Outdoor unit model			MUZ-HE24NA
Capacity Rated (Minimum~Maximum)	Cooling ※1	Btu/h	22,500 (8,200 ~ 22,500)
	Heating 47 ※1	Btu/h	26,600 (7,500 ~ 30,000)
Power consumption Rated	Cooling ※1	W	2,620
	Heating 47 ※1	W	2,150
EER ※1 [SEER] ※2	Cooling		8.6 [18.0]
HSPF IV ※3	Heating		8.5
COP	Heating ※1		3.62
Power supply	V , phase , Hz		208/230 , 1 , 60
Max. fuse size (time delay)		A	20
Min. circuit ampacity		A	17.1
Fan motor		F.L.A	0.93
Compressor	Model		SNB172FQKMT
	R.L.A		12.9
	L.R.A		16.1
	Refrigeration oil (Model)	L	0.40 (FV50S)
Refrigerant control			Linear expansion valve
Sound level ※1	Cooling	dB(A)	55
	Heating	dB(A)	55
Defrost method			Reverse cycle
Dimensions	W	in.	33-1/16
	D	in.	13
	H	in.	34-5/8
Weight		lb.	119
External finish			Munsell 3Y 7.8/1.1
Remote controller			Wireless type
Control voltage (by built-in transformer)		VDC	12-24
Refrigerant piping			Not supplied
Refrigerant pipe size (Min. wall thickness)	Liquid	in.	3/8 (0.0315)
	Gas	in.	5/8 (0.0315)
Connection method	Indoor		Flared
	Outdoor		Flared
Between the indoor & outdoor units	Height difference	ft.	50
	Piping length	ft.	100
Refrigerant charge (R410A)			4 lb. 3 oz.

NOTE: Test conditions are based on AHRI 210/240.

※1: Rating conditions (Cooling) — Indoor: 80°FDB, 67°FWB, Outdoor: 95°FDB, (75°FWB)
(Heating) — Indoor: 70°FDB, 60°FWB, Outdoor: 47°FDB, 43°FWB

Test condition

*2,*3

ARI	Mode	Test	Indoor air condition (°F)		Outdoor air condition (°F)	
			Dry bulb	Wet bulb	Dry bulb	Wet bulb
	SEER (Cooling)	"A-2" Cooling Steady State at rated compressor Speed	80	67	95	(75)
		"B-2" Cooling Steady State at rated compressor Speed	80	67	82	(65)
		"B-1" Cooling Steady State at minimum compressor Speed	80	67	82	(65)
		"F-1" Cooling Steady State at minimum compressor Speed	80	67	67	(53.5)
		"E-V" Cooling Steady State at Intermediate compressor Speed *4	80	67	87	(69)
	HSPF (Heating)	"H1-2" Heating Steady State at rated compressor Speed	70	60	47	43
		"H3-2" Heating at rated compressor Speed	70	60	17	15
		"H0-1" Heating Steady State at minimum compressor Speed	70	60	62	56.5
		"H1-1" Heating Steady State at minimum compressor Speed	70	60	47	43
		"H2-V" Heating at Intermediate compressor Speed *4	70	60	35	33

*4: At Intermediate compressor Speed

= ("Cooling rated compressor speed" - "minimum compressor speed") / 3 + "minimum compressor speed".

3-1. OPERATING RANGE

(1) POWER SUPPLY

	Rated voltage	Guaranteed voltage (V)
Outdoor unit	208/230 V 1 phase 60 Hz	Min. 187 208 230 Max. 253

(2) OPERATION




Mode	Condition	Intake air temperature (°F)			
		Indoor		Outdoor	
		DB	WB	DB	WB
Cooling	Standard temperature	80	67	95	—
	Maximum temperature	90	73	115	—
	Minimum temperature	67	57	14	—
	Maximum humidity	78 %		—	
Heating	Standard temperature	70	60	47	43
	Maximum temperature	80	67	75	65
	Minimum temperature	70	60	-4	-5

4

OUTLINES AND DIMENSIONS


MUZ-HE09NA MUZ-HE12NA MUZ-HE15NA

Unit: inch



REQUIRED SPACE


*1 4 in. or more when front and sides of the unit are clear



*2 When any 2 sides of left, right and rear of the unit are clear


MUZ-HE18NA

Unit: inch




REQUIRED SPACE

*1 20 in. or more when front and sides of the unit are clear



*2 When any 2 sides of left, right and rear of the unit are clear







MUZ-HE24NA


Unit: inch

REQUIRED SPACE

*1 20 in. or more when front and sides of the unit are clear




MUZ-HE09NA MUZ-HE12NA




SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
C62, C63	SMOOTHING CAPACITOR	LEV	EXPANSION VALVE COIL	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR.
DB61, DB65	DIODE MODULE	MC	COMPRESSOR	TB1, TB2	TERMINAL BLOCK
F701, F801, F901	FUSE (T3, 15A/250V)	MF	FAN MOTOR	TR821	SWITCHING POWER TRANSISTOR
H	DEFROST HEATER(OPTION PARTS)	PTC64, PTC65	CIRCUIT PROTECTION	T801	TRANSFORMER
IC802	POWER DEVICE	RT61	DEFROST THERMISTOR	X63, X64, X66	RELAY
IPM, IC932	POWER MODULE	RT62	DISCHARGE TEMP. THERMISTOR	21S4	REVERSING VALVE COIL
L61	REACTOR	RT64	FIN TEMP. THERMISTOR	26H	HEATER PROTECTOR(OPTION PARTS)
LED	LED	RT65	AMBIENT TEMP. THERMISTOR		

MUZ-HE15NA




SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
C61, C62, C63	SMOOTHING CAPACITOR	LEV	EXPANSION VALVE COIL	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR.
DB61, DB65	DIODE MODULE	MC	COMPRESSOR	TB1, TB2	TERMINAL BLOCK
F701, F801, F901	FUSE (T3, 15A/250V)	MF	FAN MOTOR	TR821	SWITCHING POWER TRANSISTOR
H	DEFROST HEATER(OPTION PARTS)	PTC64, PTC65	CIRCUIT PROTECTION	T801	TRANSFORMER
IC802	POWER DEVICE	RT61	DEFROST THERMISTOR	X63, X64, X66	RELAY
IPM, IC932	POWER MODULE	RT62	DISCHARGE TEMP. THERMISTOR	21S4	REVERSING VALVE COIL
L61	REACTOR	RT64	FIN TEMP. THERMISTOR	26H	HEATER PROTECTOR(OPTION PARTS)
LED	LED	RT65	AMBIENT TEMP. THERMISTOR		

MUZ-HE18NA



SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
C61, C62, C63	SMOOTHING CAPACITOR	LEV	EXPANSION VALVE COIL	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR.
DB61, DB65	DIODE MODULE	MC	COMPRESSOR		
F701, F801, F901	FUSE (T3, 15A/250V)	MF	FAN MOTOR	TB1, TB2	TERMINAL BLOCK
H	DEFROST HEATER (OPTION PARTS)	PTC64, PTC65	CIRCUIT PROTECTION	TR821	SWITCHING POWER TRANSISTOR
HC930, IPM	POWER MODULE	RT61	DEFROST THERMISTOR	T801	TRANSFORMER
IC802	POWER DEVICE	RT62	DISCHARGE TEMP. THERMISTOR	X63, X64, X66	RELAY
L61	REACTOR	RT64	FIN TEMP. THERMISTOR	21S4	REVERSING VALVE COIL
LED	LED	RT65	AMBIENT TEMP. THERMISTOR	26H	HEATER PROTECTOR (OPTION PARTS)

MUZ-HE24NA




SYMBOL	NAME	SYMBOL	NAME
CB1~3	SMOOTHING CAPACITOR	PTC64	CIRCUIT PROTECTION
F601	FUSE (T3. 15A/250V)	PTC65	CIRCUIT PROTECTION
F62	FUSE (T2A/250V)	RT61	DEFROST THERMISTOR
F65, F66	FUSE (T6. 3A/250V)	RT62	DISCHARGE TEMP. THERMISTOR
F880	FUSE (T3. 15A/250V)	RT64	FIN TEMP. THERMISTOR
F901	FUSE (T3. 15A/250V)	RT65	AMBIENT TEMP. THERMISTOR
IC932	INTELLIGENT POWER MODULE	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
IPM	INTELLIGENT POWER MODULE	TB1, TB2	TERMINAL BLOCK
L	REACTOR	T801	TRANSFORMER
LEV	EXPANSION VALVE COIL	X601, X602	RELAY
MC	COMPRESSOR	X64	RELAY
MF	FAN MOTOR	21S4	REVERSING VALVE COIL
PFC	POWER FACTOR CONTROLLER		


- NOTES
1. About the indoor side electric wiring, refer to the indoor unit electric wiring diagram for servicing.
 2. Use copper conductors only (for field wiring).
 3. Symbols indicate. : Terminal block

MUZ-HE09NA

Unit: inch




MUZ-HE12NA MUZ-HE15NA




MUZ-HE18NA

Unit: inch




MUZ-HE24NA



MAX. REFRIGERANT PIPING LENGTH and MAX. HEIGHT DIFFERENCE

Model	Refrigerant piping: ft.		Piping size O.D: in.	
	Max. Length A	Max. Height difference B	Gas	Liquid
MUZ-HE09/12/15NA	65	40	3/8 (HE09/12) 1/2 (HE15)	1/4
MUZ-HE18NA	100	50	1/2	
MUZ-HE24NA	100	50	5/8	3/8



ADDITIONAL REFRIGERANT CHARGE (R410A: oz.)

NOTE: Refrigerant piping exceeding 25 ft. requires additional refrigerant charge according to the calculation.

Model	Outdoor unit precharged	Refrigerant piping length (one way): ft.					
		25	30	40	50	60	65
MUZ-HE09NA	1 lb. 12 oz.	0	1.62	4.86	8.10	11.34	12.96
MUZ-HE12NA	2 lb. 9 oz.						
MUZ-HE15NA							

Calculation: X oz. = 1.62/5 oz. / ft. × (Refrigerant piping length (ft.) - 25)

Model	Outdoor unit precharged	Refrigerant piping length (one way): ft.								
		25	30	40	50	60	70	80	90	100
MUZ-HE18NA	3 lb. 7 oz.	0	1.08	3.24	5.40	7.56	9.72	11.88	14.04	16.20

Calculation: X oz. = 1.08/5 oz. / ft. × (Refrigerant piping length (ft.) - 25)

NOTE: Refrigerant piping exceeding 33 ft. requires additional refrigerant charge according to the calculation.

Model	Outdoor unit precharged	Refrigerant piping length (one way): ft.							
		33	40	50	60	70	80	90	100
MUZ-HE24NA	4 lb. 3 oz.	0	4.14	10.06	15.98	21.90	27.82	33.74	39.66

Calculation: X oz. = 2.96/5 oz. / ft. × (Refrigerant piping length (ft.) - 33)

7-1. PERFORMANCE DATA

1) COOLING CAPACITY

MUZ-HE09NA MUZ-HE12NA MUZ-HE15NA MUZ-HE18NA MUZ-HE24NA

Model	Indoor air IWB (°F)	Outdoor intake air DB temperature (°F)														
		75			85			95			105			115		
		TC	SHC	TPC	TC	SHC	TPC	TC	SHC	TPC	TC	SHC	TPC	TC	SHC	TPC
MUZ-HE09NA	71	11.0	7.6	0.67	10.3	7.1	0.73	9.7	6.6	0.79	9.0	6.2	0.83	8.3	5.7	0.86
	67	10.4	8.6	0.63	9.7	8.0	0.69	9.0	7.4	0.75	8.4	6.9	0.80	7.7	6.3	0.83
	63	9.8	9.4	0.60	9.1	8.7	0.66	8.5	8.1	0.72	7.7	7.3	0.77	7.0	6.7	0.80
MUZ-HE12NA	71	14.7	9.4	1.08	13.7	8.7	1.18	12.9	8.2	1.27	12.0	7.6	1.34	11.0	7.0	1.39
	67	13.9	10.7	1.02	13.0	10.0	1.12	12.0	9.2	1.21	11.2	8.6	1.28	10.3	7.9	1.34
	63	13.1	11.8	0.97	12.1	10.9	1.07	11.3	10.2	1.16	10.3	9.3	1.23	9.4	8.5	1.28
MUZ-HE15NA	71	17.2	11.1	1.04	16.0	10.4	1.14	15.1	9.7	1.23	14.0	9.1	1.29	12.9	8.3	1.35
	67	16.2	12.7	0.98	15.1	11.8	1.08	14.0	10.9	1.17	13.0	10.2	1.24	12.0	9.3	1.30
	63	15.3	13.9	0.94	14.1	12.9	1.04	13.2	12.0	1.12	12.0	10.9	1.19	10.9	10.0	1.24
MUZ-HE18NA	71	21.1	12.2	1.46	19.7	11.4	1.60	18.5	10.7	1.72	17.2	9.9	1.81	15.8	9.1	1.89
	67	20.0	14.2	1.38	18.6	13.2	1.52	17.2	12.2	1.64	16.0	11.4	1.74	14.7	10.4	1.82
	63	18.7	15.8	1.31	17.4	14.7	1.45	16.2	13.6	1.57	14.7	12.4	1.67	13.4	11.3	1.74
MUZ-HE24NA	71	27.6	17.0	2.33	25.8	15.9	2.55	24.2	14.9	2.75	22.5	13.9	2.90	20.7	12.8	3.01
	67	26.1	19.6	2.20	24.3	18.2	2.42	22.5	16.9	2.62	20.9	15.7	2.78	19.2	14.4	2.91
	63	24.5	21.7	2.10	22.7	20.1	2.32	21.1	18.7	2.50	19.2	17.0	2.67	17.6	15.5	2.78

NOTE: 1. IWB: Intake air wet-bulb temperature

TC: Total Capacity ($\times 10^3$ Btu/h)SHC: Sensible Heat Capacity ($\times 10^3$ Btu/h)

TPC: Total Power Consumption (kW)

2. SHC is based on 80°F of indoor Intake air DB temperature.

2) COOLING CAPACITY CORRECTIONS

Model	Refrigerant piping length (one way: ft.)			
	25 (std.)	40	65	100
MUZ-HE09NA MUZ-HE12NA MUZ-HE15NA MUZ-HE18NA	1.0	0.954	0.878	—
MUZ-HE24NA	1.0	0.954	0.878	0.771

3) HEATING CAPACITY

Model	Indoor air IDB (°F)	Outdoor intake air WB temperature (°F)													
		5		15		25		35		43		45		55	
		TC	TPC	TC	TPC	TC	TPC	TC	TPC	TC	TPC	TC	TPC	TC	TPC
MUZ-HE09NA	75	4.8	0.53	6.3	0.67	7.9	0.79	9.4	0.88	10.6	0.92	11.0	0.94	12.4	0.97
	70	5.2	0.51	6.7	0.65	8.2	0.77	9.6	0.86	10.9	0.90	11.2	0.92	12.7	0.95
	65	5.5	0.49	6.9	0.62	8.6	0.74	10.0	0.83	11.2	0.88	11.6	0.89	13.0	0.94
MUZ-HE12NA	75	5.4	0.58	7.1	0.74	8.8	0.87	10.6	0.97	11.9	1.01	12.3	1.03	13.9	1.07
	70	5.8	0.56	7.5	0.71	9.2	0.85	10.8	0.94	12.2	0.99	12.6	1.01	14.2	1.05
	65	6.1	0.53	7.7	0.68	9.6	0.82	11.2	0.92	12.6	0.97	12.9	0.98	14.5	1.03
MUZ-HE15NA	75	7.9	0.94	10.4	1.19	13.1	1.40	15.6	1.56	17.6	1.64	18.1	1.66	20.5	1.73
	70	8.6	0.90	11.1	1.15	13.5	1.37	15.9	1.52	18.0	1.60	18.5	1.63	21.0	1.70
	65	9.0	0.86	11.3	1.10	14.1	1.32	16.5	1.48	18.5	1.56	19.1	1.58	21.4	1.66
MUZ-HE18NA	75	7.9	0.94	10.4	1.18	13.1	1.39	15.6	1.55	17.6	1.63	18.1	1.65	20.5	1.72
	70	8.6	0.90	11.1	1.14	13.5	1.36	15.9	1.51	18.0	1.59	18.5	1.62	21.0	1.69
	65	9.0	0.86	11.3	1.10	14.1	1.31	16.5	1.47	18.5	1.55	19.1	1.57	21.4	1.65
MUZ-HE24NA	75	11.7	1.27	15.4	1.60	19.3	1.88	23.0	2.10	25.9	2.20	26.7	2.24	30.3	2.32
	70	12.6	1.21	16.4	1.55	20.0	1.84	23.5	2.04	26.6	2.15	27.4	2.19	31.0	2.28
	65	13.3	1.16	16.8	1.48	20.9	1.77	24.3	1.99	27.4	2.10	28.2	2.13	31.7	2.24

NOTE: 1. IDB: Intake air dry-bulb temperature

TC: Total Capacity (x10³ Btu/h)

TPC: Total Power Consumption (kW)


2. Above data is for heating operation without any frost.

How to operate with fixed operational frequency of the compressor.


1. Press the EMERGENCY OPERATION switch on the front of the indoor unit, and select either EMERGENCY COOL mode or EMERGENCY HEAT mode before starting to operate the air conditioner.
2. The compressor starts with operational frequency.
3. The fan speed of the indoor unit is High.
4. This operation continues for 30 minutes.
5. In order to release this operation, press the EMERGENCY OPERATION switch twice or once, or press any button on the remote controller.

7-2. PERFORMANCE CURVE


Cooling




MUZ-HE09NA




MUZ-HE12NA




MUZ-HE15NA




MUZ-HE18NA




MUZ-HE24NA




Heating




MUZ-HE09NA



MUZ-HE12NA




MUZ-HE15NA




This value of frequency is not the same as the actual frequency in operating. Refer to 7-5 and 7-6 for the relationships between frequency and capacity.

MUZ-HE18NA



MUZ-HE24NA



This value of frequency is not the same as the actual frequency in operating. Refer to 7-5 and 7-6 for the relationships between frequency and capacity.



7-3. CONDENSING PRESSURE

Cooling



Data is based on the condition of indoor humidity 50 %.

Air flow should be set to High speed.



MUZ-HE09NA





MUZ-HE12NA





MUZ-HE15NA



MUZ-HE18NA



MUZ-HE24NA





Heating

Data is based on the condition of outdoor humidity 75%.



Air flow should be set to High speed.

Data is for heating operation without any frost.



MUZ-HE09NA





MUZ-HE12NA





MUZ-HE15NA



MUZ-HE18NA



MUZ-HE24NA



7-4. STANDARD OPERATION DATA

Model			MSZ-HE09NA		MSZ-HE12NA		
Item		Unit	Cooling	Heating	Cooling	Heating	
Total	Capacity	Btu/h	9,000	10,900	12,000	14,400	
	SHF	-	0.82	—	0.77	—	
	Input	kW	0.750	0.900	1.210	0.990	
	Rated frequency	Hz	59.5	77.5	69.0	77.0	
	Indoor unit		MSZ-HE09NA		MSZ-HE12NA		
Electrical circuit	Power supply (V, Phase, Hz)		208/230, 1, 60				
	Input	kW	0.022	0.023	0.022	0.023	
	Fan motor current	A	0.24/0.22	0.25/0.23	0.24/0.22	0.25/0.23	
	Outdoor unit		MUZ-HE09NA		MUZ-HE12NA		
	Power supply (V, phase, Hz)		208/230, 1, 60				
	Input	kW	0.728	0.877	1.188	0.967	
	Comp. current	A	3.32/3.00	3.66/3.31	4.39/3.97	5.41/4.89	
	Fan motor current	A	0.27/0.24	0.30/0.27	0.34/0.31	0.31/0.28	
	Refrigerant circuit	Condensing pressure	PSIG	389	331	389	397
Suction pressure		PSIG	151	103	133	104	
Discharge temperature		°F	154	152	163	162	
Condensing temperature		°F	115	103	115	116	
Suction temperature		°F	59	39	56	35	
Comp. shell bottom temp		°F	151	149	158	158	
Ref. pipe length		ft.	25				
Refrigerant charge (R410A)		-	1 lb. 12 oz.		2 lb. 9 oz.		
Indoor unit	Intake air temperature	DB	°F	80	70	80	70
		WB	°F	67	60	67	60
	Discharge air temperature	DB	°F	60	97	56	108
		WB	°F	58	—	55	—
	Fan speed (High)	rpm	1,020	1,040	1,020	1,040	
	Airflow (High)	CFM	367 (Wet)	413	367 (Wet)	413	
Outdoor unit	Intake air temperature	DB	°F	95	47	95	47
		WB	°F	—	43	—	43
	Fan speed	rpm	800	850	900	860	
	Airflow	CFM	1151	1225	1229	1172	




Model			MSZ-HE15NA		MSZ-HE18NA	
Item		Unit	Cooling	Heating	Cooling	Heating
Total	Capacity	Btu/h	14,000	18,000	17,200	18,000
	SHF	-	0.78	—	0.71	—
	Input	kW	1.170	1.600	1.640	1.590
	Rated frequency	Hz	55.5	74.0	83.0	84.0
	Indoor unit		MSZ-HE15NA		MSZ-HE18NA	
Power supply (V, Phase, Hz)		208/230, 1, 60				
Electrical circuit	Input	kW	0.043	0.030	0.043	0.039
	Fan motor current	A	0.50/0.45	0.35/0.32	0.43/0.39	0.40/0.36
	Outdoor unit		MUZ-HE15NA		MUZ-HE18NA	
	Power supply (V, phase, Hz)		208/230, 1, 60			
	Input	kW	1.127	1.570	1.597	1.551
	Comp. current	A	4.86/4.40	7.38/6.67	6.97/6.29	8.36/7.55
	Fan motor current	A	0.33/0.30	0.34/0.31	0.80/0.72	0.64/0.59
	Refrigerant circuit					
Condensing pressure	PSIG	400	431	376	458	
Suction pressure	PSIG	139	99	117	102	
Discharge temperature	°F	164	179	177	184	
Condensing temperature	°F	117	122	112	127	
Suction temperature	°F	57	31	59	33	
Comp. shell bottom temp	°F	148	165	164	170	
Ref. pipe length	ft.	25				
Refrigerant charge (R410A)	-	2 lb. 9 oz.		3 lb. 7 oz.		
Indoor unit	Intake air temperature	DB	°F	80	70	80
		WB	°F	67	60	67
	Discharge air temperature	DB	°F	60	114	56
		WB	°F	57	—	54
	Fan speed (High)	rpm	1,280	1,140	1,280	1,240
	Airflow (High)	CFM	498 (Wet)	463	498 (Wet)	512
Outdoor unit	Intake air temperature	DB	°F	95	47	47
		WB	°F	—	43	43
	Fan speed	rpm	910	900	780	740
	Airflow	CFM	1,243	1,229	1,730	1,659


Model				MSZ-HE24NA		
Item			Unit	Cooling	Heating	
Total	Capacity		Btu/h	22,500	26,600	
	SHF		-	0.75	—	
	Input		kW	2.620	2.150	
	Rated frequency		Hz	66.5	82.0	
	Indoor unit			MSZ-HE24NA		
Electrical circuit	Power supply (V, Phase, Hz)		208/230, 1, 60			
	Input		kW	0.058		
	Fan motor current		A	0.56/0.51		
	Outdoor unit			MUZ-HE24NA		
	Power supply (V, phase, Hz)		208/230, 1, 60			
	Input		kW	2.562	2.092	
	Comp. current		A	7.01/6.34	9.59/8.67	
	Fan motor current		A	1.61/1.05	1.13/1.02	
	Refrigerant circuit	Condensing pressure		PSIG	395	405
		Suction pressure		PSIG	141	102
Discharge temperature		°F	158	171		
Condensing temperature		°F	115			
Suction temperature		°F	52	33		
Comp. shell bottom temp		°F	140	148		
Ref. pipe length		ft.	25			
Refrigerant charge (R410A)		-	4 lb. 3 oz.			
Indoor unit	Intake air temperature	DB	°F	80	70	
		WB	°F	67	60	
	Discharge air temperature	DB	°F	56	111	
		WB	°F	53	—	
	Fan speed (High)		rpm	1,300		
	Airflow (High)		CFM	634 (Wet)	738	
Outdoor unit	Intake air temperature	DB	°F	95	47	
		WB	°F	—	43	
	Fan speed		rpm	840	810	
	Airflow		CFM	1,769	1,701	

7-5. CAPACITY AND INPUT CORRECTION BY INVERTER OUTPUT FREQUENCY


MUZ-HE09NA




MUZ-HE12NA




MUZ-HE15NA



MUZ-HE18NA



MUZ-HE24NA



7-6. HOW TO OPERATE FIXED-FREQUENCY OPERATION (Test run operation)

1. Press EMERGENCY OPERATION switch to start COOL or HEAT mode (COOL: Press once, HEAT: Press twice).
2. Test run operation starts and continues to operate for 30 minutes.
3. Compressor operates at rated frequency in COOL mode or 58 Hz in HEAT mode.
4. Indoor fan operates at High speed.
5. After 30 minutes, test run operation finishes and EMERGENCY OPERATION starts (operation frequency of compressor varies).
6. To cancel test run operation (EMERGENCY OPERATION), press EMERGENCY OPERATION switch or any button on remote controller.


MUZ-HE09NA MUZ-HE12NA MUZ-HE15NA MUZ-HE18NA MUZ-HE24NA

8-1. OUTDOOR FAN MOTOR CONTROL

The fan motor turns ON/OFF, interlocking with the compressor.

[ON] The fan motor turns ON 5 seconds before the compressor starts up.

[OFF] The fan motor turns OFF 15 seconds after the compressor has stopped running.




8-2. R.V. COIL CONTROL

Heating ON

Cooling OFF

Dry OFF

NOTE: The 4-way valve reverses for 5 seconds right before start-up of the compressor.



8-3. RELATION BETWEEN MAIN SENSOR AND ACTUATOR

Sensor	Purpose	Actuator				
		Compressor	LEV	Outdoor fan motor	R.V.coil	Indoor fan motor
Discharge temperature thermistor	Protection	○	○			
Indoor coil temperature thermistor	Cooling: Coil frost prevention	○				
	Heating: High pressure protection	○	○			
Defrost thermistor	Heating: Defrosting	○	○	○	○	○
Fin temperature thermistor	Protection	○		○		
Ambient temperature thermistor	Cooling: Low ambient temperature operation	○	○	○		
Outdoor heat exchanger temperature thermistor	Cooling: Low ambient temperature operation	○	○	○		
	Cooling: High pressure protection	○	○	○		

MUZ-HE09NA MUZ-HE12NA MUZ-HE15NA MUZ-HE18NA MUZ-HE24NA

9-1. CHANGE IN DEFROST SETTING

Changing defrost finish temperature

<JS> To change the defrost finish temperature, cut/solder the JS wire of the outdoor inverter P.C. board. (Refer to 10-6.1.)

Jumper		Defrost finish temperature				
		MUZ-HE09	MUZ-HE12	MUZ-HE15	MUZ-HE18	MUZ-HE18/24
JS	Soldered (Initial setting)	41°F (5°C)	50°F (10°C)	41°F (5°C)	48°F (9°C)	50°F (10°C)
	None (Cut)	46°F (8°C)	55°F (13°C)	50°F (10°C)	64°F (18°C)	64°F (18°C)

9-2. PRE-HEAT CONTROL SETTING

PRE-HEAT CONTROL

When moisture gets into the refrigerant cycle, it may interfere the start-up of the compressor at low outside temperature. The pre-heat control prevents this interference. The pre-heat control turns ON when the discharge temperature thermistor is 68°F (20°C) or below. When pre-heat control turns ON, compressor is energized. (About 50 W)

Pre-heat control setting

<JK> ON: To activate the pre-heat control, cut the JK wire of the inverter P.C. board. (Refer to 10-6.1.)

OFF: To deactivate the pre-heat control, solder JK wire of the inverter P.C. board. (Refer to 10-6.1.)

NOTE: When the inverter P.C. board is replaced, check the Jumper wires, and cut/solder them if necessary.

MUZ-HE09NA MUZ-HE12NA MUZ-HE15NA MUZ-HE18NA MUZ-HE24NA

10-1. CAUTIONS ON TROUBLESHOOTING

1. Before troubleshooting, check the following

- 1) Check the power supply voltage.
- 2) Check the indoor/outdoor connecting wire for miswiring.

2. Take care of the following during servicing

- 1) Before servicing the air conditioner, be sure to turn OFF the main unit first with the remote controller, then after confirming the horizontal vane is closed, turn off the breaker and/or disconnect the power plug.
- 2) Be sure to turn OFF the power supply before removing the front panel, the cabinet, the top panel, and the electronic control P.C. board.
- 3) When removing the electrical parts, be careful of the residual voltage of smoothing capacitor.
- 4) When removing the electronic control P.C. board, hold the edge of the board with care NOT to apply stress on the components.
- 5) When connecting or disconnecting the connectors, hold the housing of the connector. DO NOT pull the lead wires.

<Incorrect>



Lead wiring

<Correct>



Housing point

3. Troubleshooting procedure

- 1) Check if the OPERATION INDICATOR lamp on the indoor unit is flashing ON and OFF to indicate an abnormality. To make sure, check how many times the OPERATION INDICATOR lamp is flashing ON and OFF before starting service work.
- 2) Before servicing, check that the connector and terminal are connected properly.
- 3) When the electronic control P.C. board seems to be defective, check the copper foil pattern for disconnection and the components for bursting and discoloration.
- 4) Refer to 10-2. and 10-3.

10-2. FAILURE MODE RECALL FUNCTION


Outline of the function

This air conditioner can memorize the abnormal condition which has occurred once.

Even though LED indication listed on the troubleshooting check table (10-3.) disappears, the memorized failure details can be recalled.


1. Flow chart of failure mode recall function for the indoor/outdoor unit

Operational procedure




NOTE: 1. Make sure to release the failure mode recall function after it is set up, otherwise the unit cannot operate properly.
2. If the abnormal condition is not deleted from the memory, the last abnormal condition is kept memorized.

※2. Blinking pattern when the indoor unit is abnormal:




※3. Blinking pattern when the outdoor unit is abnormal:




2. Flow chart of the detailed outdoor unit failure mode recall function

Operational procedure



NOTE: 1. Make sure to release the failure mode recall function after it is set up, otherwise the unit cannot operate properly.
2. If the abnormal condition is not deleted from the memory, the last abnormal condition is kept memorized.

※2. Blinking pattern when outdoor unit is abnormal:



3. Outdoor unit failure mode table

OPERATION INDICATOR upper lamp (Indoor unit)	Abnormal point (Failure mode / protection)	LED indication (Outdoor P.C. board)	Condition	Remedy	Indoor/ outdoor unit failure mode recall function	Outdoor unit failure mode recall function
OFF	None (Normal)	—	—	—	—	—
2-time flash 2.5 seconds OFF	Outdoor power system	—	Overcurrent protection cut-out operates 3 consecutive times within 1 minute after the compressor gets started.	•Reconnect connectors. •Refer to 10-5. Ⓐ "How to check inverter/ compressor". •Check the stop valve.	○	○
3-time flash 2.5 seconds OFF	Discharge temperature thermistor	1-time flash every 2.5 seconds	Thermistor shorts or opens during compressor running.	•Refer to 10-5. Ⓒ "Check of outdoor thermistors". Defective outdoor thermistors can be identified by checking the blinking pattern of LED.	○	○
	Defrost thermistor					
	Fin temperature thermistor	3-time flash 2.5 seconds OFF				
	P.C. board temperature thermistor	4-time flash 2.5 seconds OFF				
	Ambient temperature thermistor	2-time flash 2.5 seconds OFF				
	Outdoor heat exchanger temperature thermistor (MUZ-HE24)					
4-time flash 2.5 seconds OFF	Overcurrent	11-time flash 2.5 seconds OFF	Large current flows into intelligent power module/ power module *1.	•Reconnect compressor connector. •Refer to 10-5. Ⓐ "How to check inverter/ compressor". •Check the stop valve.	—	○
	Compressor synchronous abnormality (Compressor start-up failure protection)	12-time flash 2.5 seconds OFF	Waveform of compressor current is distorted.	•Reconnect compressor connector. •Refer to 10-5. Ⓐ "How to check inverter/ compressor".	—	○
5-time flash 2.5 seconds OFF	Discharge temperature	—	Temperature of discharge temperature thermistor exceeds 241°F (116°C), compressor stops. Compressor can restart if discharge temperature thermistor reads 212°F (100°C) or less 3 minutes later.	•Check the refrigerant circuit and the refrigerant amount. •Refer to 10-5. Ⓒ "Check of LEV".	—	○
6-time flash 2.5 seconds OFF	High pressure	—	Temperature of indoor coil thermistor exceeds 158°F (70°C) in HEAT mode. Temperature of outdoor heat exchanger temperature thermistor exceeds 158°F (70°C) in COOL mode.	•Check the refrigerant circuit and the refrigerant amount. •Check the stop valve.	—	○
7-time flash 2.5 seconds OFF	Fin temperature/ P.C. board temperature	7-time flash 2.5 seconds OFF	Temperature of fin temperature thermistor on the inverter P.C. board exceeds 167 ~ 176°F (75 ~ 80°C), or temperature of P.C. board temperature thermistor on the inverter P.C. board exceeds 158 ~ 167°F (70 ~ 75°C).	•Check around the outdoor unit. •Check the outdoor unit air passage. •Refer to 10-5. ① "Check of outdoor fan motor".	—	○
8-time flash 2.5 seconds OFF	Outdoor fan motor	—	Outdoor fan has stopped 3 times in a row within 30 seconds after outdoor fan start-up.	•Refer to 10-5. ① "Check of outdoor fan motor". Refer to 10-5. ② "Check of inverter P.C. board".	—	○
9-time flash 2.5 seconds OFF	Nonvolatile memory data	5-time flash 2.5 seconds OFF	Nonvolatile memory data cannot be read properly.	•Replace the inverter P.C. board.	○	○
	Power module (MUZ-HE24NA)	6-time flash 2.5 seconds OFF	The interphase short circuit occurs in the output of the intelligent power module (IPM)/power module (IPM) *1. The compressor winding shorts circuit.	•Refer to 10-5. Ⓐ "How to check inverter/ compressor".		
10-time flash 2.5 seconds OFF	Discharge temperature	—	Temperature of discharge temperature thermistor has been 122°F (50°C) or less for 20 minutes.	•Refer to 10-5. Ⓒ "Check of LEV". •Check the refrigerant circuit and the refrigerant amount.	—	○

NOTE: Blinking patterns of this mode differ from the ones of Troubleshooting check table (10-3.).

*1

Intelligent power module: **MUZ-HE24NA**

Power module: **Other models**



OPERATION INDICATOR upper lamp (Indoor unit)	Abnormal point (Failure mode / protection)	LED indication (Outdoor P.C. board)	Condition	Remedy	Indoor/ outdoor unit failure mode recall function	Outdoor unit failure mode recall function
11-time flash 2.5 seconds OFF	DC voltage	8-time flash 2.5 seconds OFF	DC voltage of inverter cannot be detected normally.	•Refer to 10-5. Ⓐ "How to check inverter/ compressor".	—	○
	Each phase current of compressor	9-time flash 2.5 seconds OFF	Each phase current of compressor cannot be detected normally.			
12-time flash 2.5 seconds OFF	Overcurrent Compressor open-phase	10-time flash 2.5 seconds OFF	Large current flows into intelligent power module (IPM)/power module (IPM) ※1. The open-phase operation of compressor is detected. The interphase short circuit occurs in the output of the intelligent power module (IPM)/power module (IPM) ※1. The compressor winding shorts circuit.	•Reconnect compressor connector. •Refer to 10-5. Ⓐ "How to check inverter/ compressor".	—	○
14-time flash 2.5 seconds OFF	Stop valve (Closed valve)	14-time flash 2.5 seconds OFF	Closed valve is detected by compressor current.	•Check the stop valve	○	○
	4-way valve/ Pipe temperature	16-time flash 2.5 seconds OFF	The 4-way valve does not work properly. The indoor coil thermistor detects an abnormal temperature.	•Check the 4-way valve. •Replace the inverter P.C. board.		

NOTE: Blinking patterns of this mode differ from the ones of Troubleshooting check table (10-3.).

※1

Intelligent power module: **MUZ-HE24NA**

Power module: **Other models**



10-3. TROUBLESHOOTING CHECK TABLE

No.	Symptom	LED indication	Abnormal point/Condition	Condition	Remedy
1	Outdoor unit does not operate.	1-time flash every 2.5 seconds	Outdoor power system	Overcurrent protection cut-out operates 3 consecutive times within 1 minute after the compressor gets started, or failure of restart of compressor has repeated 24 times.	•Reconnect connector of compressor. •Refer to 10-5.④ "How to check inverter/compressor". •Check the stop valve.
2			Outdoor thermistors	Discharge temperature thermistor, fin temperature thermistor, defrost thermistor, outdoor heat exchanger temperature thermistor, P.C. board temperature thermistor or ambient temperature thermistor shorts or opens during compressor running.	•Refer to 10-5.⑥ "Check of outdoor thermistors".
3			Outdoor control system	Nonvolatile memory data cannot be read properly. (The upper lamp of OPERATION INDICATOR of the indoor unit lights up or flashes 7 times.)	•Replace inverter P.C. board.
4		6-time flash 2.5 seconds OFF	Serial signal	The communication fails between the indoor and outdoor unit for 3 minutes.	•Refer to 10-5.⑩ "How to check miswiring and serial signal error."
5		11-time flash 2.5 seconds OFF	Stop valve/ Closed valve	Closed valve is detected by compressor current.	•Check the stop valve.
6		14-time flash 2.5 seconds OFF	Outdoor unit (Other abnormality)	Outdoor unit is defective.	•Refer to 10-2.2. "Flow chart of the detailed outdoor unit failure mode recall function".
7		16-time flash 2.5 seconds OFF	4-way valve/ Pipe temperature	The 4-way valve does not work properly. The indoor coil thermistor detects an abnormal temperature.	•Refer to 10-5.⑧ "Check of R.V. coil". •Replace the inverter P.C. board.
8	'Outdoor unit stops and re-starts 3 minutes later' is repeated.	2-time flash 2.5 seconds OFF	Overcurrent protection	Large current flows into intelligent power module/power module ※1. ※ When overcurrent protection occurs within 10 seconds after compressor starts, compressor restarts after 15 seconds (MUZ-HE09/12/15/18NA) .	•Reconnect connector of the compressor. •Refer to 10-5.④ "How to check inverter/compressor". •Check the stop valve.
9		3-time flash 2.5 seconds OFF	Discharge temperature overheat protection	Temperature of discharge temperature thermistor exceeds 241°F (116°C), compressor stops. Compressor can restart if discharge temperature thermistor reads 212°F (100°C) or less 3 minutes later.	•Check the refrigerant circuit and the refrigerant amount. •Refer to 10-5.③ "Check of LEV".
10		4-time flash 2.5 seconds OFF	Fin temperature /P.C. board temperature thermistor overheat protection	Temperature of fin temperature thermistor on the heat sink exceeds 167 ~ 176°F (75 ~ 80°C) or temperature of P.C. board temperature thermistor on the inverter P.C. board exceeds 158 ~ 167°F (70 ~ 75°C).	•Check around the outdoor unit. •Check the outdoor unit air passage. •Refer to 10-5.① "Check of outdoor fan motor".
11		5-time flash 2.5 seconds OFF	High pressure protection	Temperature of indoor coil thermistor exceeds 158°F (70°C) in HEAT mode. Temperature of outdoor heat exchanger temperature thermistor exceeds 158°F (70°C) in COOL mode.	•Check the refrigerant circuit and the refrigerant amount. •Check the stop valve.
12		8-time flash 2.5 seconds OFF	Compressor synchronous abnormality	The waveform of compressor current is distorted.	•Reconnect connector of the compressor. •Refer to 10-5.④ "How to check inverter/compressor".
13		10-time flash 2.5 seconds OFF	Outdoor fan motor	Outdoor fan has stopped 3 times in a row within 30 seconds after outdoor fan start-up.	•Refer to 10-5.① "Check of outdoor fan motor". •Refer to 10-5.⑨ "Check of inverter P.C. board."
14		12-time flash 2.5 seconds OFF	Each phase current of compressor	Each phase current of compressor cannot be detected normally.	•Refer to 10-5.④ "How to check inverter/compressor".
15		13-time flash 2.5 seconds OFF	DC voltage	DC voltage of inverter cannot be detected normally.	•Refer to 10-5.④ "How to check inverter/compressor".
16		1-time flash 2.5 seconds OFF	Frequency drop by current protection	Current from power outlet is nearing Max. fuse size.	The unit is normal, but check the following.
17		3-time flash 2.5 seconds OFF	Frequency drop by high pressure protection	Temperature of indoor coil thermistor exceeds 131°F (55°C) in HEAT mode, compressor frequency lowers.	•Check if the indoor filters are clogged. •Check if the refrigerant is short.
			Frequency drop by defrosting in COOL mode	Indoor coil thermistor reads 46°F (8°C) or less in COOL mode, compressor frequency lowers.	•Check if the indoor/outdoor unit air circulation is short cycled.
18	Outdoor unit operates.	4-time flash 2.5 seconds OFF	Frequency drop by discharge temperature protection	Temperature of discharge temperature thermistor exceeds 232°F (111°C), compressor frequency lowers.	•Check the refrigerant circuit and the refrigerant amount. •Refer to 10-5.③ "Check of LEV". •Refer to 10-5.⑥ "Check of outdoor thermistors".

NOTE: 1. The location of LED is illustrated at the right figure. Refer to 10-6.1.

2. LED is lighted during normal operation.

The flashing frequency shows the number of times the LED blinks after every 2.5-second OFF. Flashing (Example) When the flashing frequency is "2".



※1



Intelligent power module: **MUZ-HE24NA**

Power module: **Other models**









No.	Symptom	LED indication	Abnormal point/ Condition	Condition	Remedy
19	Outdoor unit operates.	7-time flash 2.5 seconds OFF	Low discharge temperature protection	Temperature of discharge temperature thermistor has been 122°F (50°C) or less for 20 minutes.	•Refer to 10-5.Ⓔ "Check of LEV". •Check the refrigerant circuit and the refrigerant amount.
20		8-time flash 2.5 seconds OFF	PAM protection PAM: Pulse Amplitude Modulation	The overcurrent flows into IGBT (Insulated Gate Bipolar transistor: TR821) or the bus-bar voltage reaches 320 V or more, PAM stops and restarts.	This is not malfunction. PAM protection will be activated in the following cases: 1 Instantaneous power voltage drop (Short time power failure) 2 When the power supply voltage is high.
			Zero cross detecting circuit	Zero cross signal for PAM control cannot be detected.	
21		9-time flash 2.5 seconds OFF	Inverter check mode	The connector of compressor is disconnected, inverter check mode starts.	•Check if the connector of the compressor is correctly connected. Refer to 10-5.Ⓐ "How to check inverter/compressor".

NOTE: 1. The location of LED is illustrated at the right figure. Refer to 10-6.1.
2. LED is lighted during normal operation.
The flashing frequency shows the number of times the LED blinks after every 2.5-second OFF. Flashing (Example) When the flashing frequency is "2".




10-4. TROUBLE CRITERION OF MAIN PARTS

MUZ-HE09NA MUZ-HE12NA MUZ-HE15NA MUZ-HE18NA MUZ-HE24NA

Part name	Check method and criterion	Figure																
Defrost thermistor (RT61)	Measure the resistance with a tester. Refer to 10-6. "Test point diagram and voltage", 1. "Inverter P.C. board", for the chart of thermistor.																	
Fin temperature thermistor (RT64)																		
Ambient temperature thermistor (RT65)																		
Outdoor heat exchanger temperature thermistor (RT68)																		
Discharge temperature thermistor (RT62)	Measure the resistance with a tester. Before measurement, hold the thermistor with your hands to warm it up. Refer to 10-6. "Test point diagram and voltage", 1. "Inverter P.C. board", for the chart of thermistor.																	
Compressor	Measure the resistance between terminals using a tester. (Temperature: -4 ~ 104°F (-20 ~ 40°C)) <table border="1"><thead><tr><th rowspan="2"></th><th colspan="4">Normal (Ω)</th></tr><tr><th>HE09</th><th>HE12</th><th>HE15/18</th><th>HE24</th></tr></thead><tbody><tr><td>U-V</td><td rowspan="3">1.36 ~ 1.93</td><td rowspan="3">1.52 ~ 2.17</td><td rowspan="3">0.78 ~ 1.11</td><td rowspan="3">0.83 ~ 1.18</td></tr><tr><td>U-W</td></tr><tr><td>V-W</td></tr></tbody></table>		Normal (Ω)				HE09	HE12	HE15/18	HE24	U-V	1.36 ~ 1.93	1.52 ~ 2.17	0.78 ~ 1.11	0.83 ~ 1.18	U-W	V-W	
	Normal (Ω)																	
	HE09	HE12	HE15/18	HE24														
U-V	1.36 ~ 1.93	1.52 ~ 2.17	0.78 ~ 1.11	0.83 ~ 1.18														
U-W																		
V-W																		
Outdoor fan motor	Measure the resistance between lead wires using a tester. (Temperature: -4 ~ 104°F (-20 ~ 40°C)) <table border="1"><thead><tr><th rowspan="2">Color of lead wire</th><th colspan="3">Normal (Ω)</th></tr><tr><th>HE09/12</th><th>HE15</th><th>HE18/24</th></tr></thead><tbody><tr><td>RED – BLK BLK – WHT WHT – RED</td><td colspan="2">28 ~ 40</td><td>11 ~ 16</td></tr></tbody></table>	Color of lead wire	Normal (Ω)			HE09/12	HE15	HE18/24	RED – BLK BLK – WHT WHT – RED	28 ~ 40		11 ~ 16						
Color of lead wire	Normal (Ω)																	
	HE09/12	HE15	HE18/24															
RED – BLK BLK – WHT WHT – RED	28 ~ 40		11 ~ 16															
R. V. coil (21S4)	Measure the resistance using a tester. (Temperature: 14 ~ 104°F (-10 ~ 40°C)) <table border="1"><thead><tr><th>Normal (kΩ)</th></tr></thead><tbody><tr><td>0.97 ~ 1.38</td></tr></tbody></table>	Normal (kΩ)	0.97 ~ 1.38															
Normal (kΩ)																		
0.97 ~ 1.38																		
Expansion valve coil (LEV)	Measure the resistance using a tester. (Temperature: 14 ~ 104°F (-10 ~ 40°C)) <table border="1"><thead><tr><th>Color of lead wire</th><th>Normal (Ω)</th></tr></thead><tbody><tr><td>WHT – RED</td><td rowspan="4">37 ~ 54</td></tr><tr><td>RED – ORN</td></tr><tr><td>YLW – BRN</td></tr><tr><td>BRN – BLU</td></tr></tbody></table>	Color of lead wire	Normal (Ω)	WHT – RED	37 ~ 54	RED – ORN	YLW – BRN	BRN – BLU										
Color of lead wire	Normal (Ω)																	
WHT – RED	37 ~ 54																	
RED – ORN																		
YLW – BRN																		
BRN – BLU																		

10-5. TROUBLESHOOTING FLOW

Ⓐ How to check inverter/compressor



Ⓑ Check of open phase

- With the connector between the compressor and intelligent power module/power module *1 disconnected, activate the inverter and check if the inverter is normal by measuring the voltage balance between the terminals.

Output voltage is 50 - 130 V. (The voltage may differ according to the tester.)

<< Operation method>>

Start cooling or heating operation by pressing EMERGENCY OPERATION switch on the indoor unit. (TEST RUN OPERATION: Refer to 7-6.)

<<Measurement point>>

at 3 points

BLK (U) - WHT (V)

BLK (U) - RED (W)

WHT(V) - RED (W)


Measure AC voltage between the lead wires at 3 points.

NOTE: 1. Output voltage varies according to power supply voltage.

2. Measure the voltage by analog type tester.

3. During this check, LED of the inverter P.C. board flashes 9 times. (Refer to 10-6.1.)

Ⓒ Check of compressor



*1

Intelligent power module: **MUZ-HE24NA**

Power module: **Other models**

D Check of compressor winding

- Disconnect the connector between the compressor and intelligent power module/power module ※1, and measure the resistance between the compressor terminals.

<<Measurement point>>

At 3 points

BLK - WHT

BLK - RED

WHT - RED

※ Measure the resistance between the lead wires at 3 points.

※1

<<Judgement>>

Refer to 10-4.

0[Ω] Abnormal [short]

Infinite [Ω] Abnormal [open]

Intelligent power module: **MUZ-HE24NA**

Power module: **Other models**

NOTE: Be sure to zero the ohmmeter before measurement.

E Check of compressor operation time

- Connect the compressor and activate the inverter. Then measure the time until the inverter stops due to over current.

<<Operation method>>


Start heating or cooling operation by pressing EMERGENCY OPERATION switch on the indoor unit.

(TEST RUN OPERATION: Refer to 7-6.)

<<Measurement>>

Measure the time from the start of compressor to the stop of compressor due to overcurrent.

<<Judgement>>



F Check of compressor start failure

Confirm that 1~4 is normal.

- Electrical circuit check



1. Contact of the compressor connector

2. Output voltage of inverter P.C. board and balance of them (See 10-5.⑥)

3. Direct current voltage between DB61(+) and (-) (**MUZ-HE09/12/15/18NA**)/

JP715(+) and JP30(-) (**MUZ-HE24NA**) on the inverter P.C. board

4. Voltage between outdoor terminal block S1-S2



※1

Heat the compressor with a drier for about 20 minutes. Do not recover refrigerant gas while heating.

G Check of outdoor thermistors

Disconnect the connector of thermistor in the inverter P.C. board (see below table), and measure the resistance of thermistor.

Is the resistance of thermistor normal? (Refer to 10-6.1.)

No

Replace the thermistor except RT64. When RT64 is abnormal, replace the inverter P.C. board.

Yes

Reconnect the connector of thermistor.
Turn ON the power supply and press EMERGENCY OPERATION switch.

Does the unit operate for 10 minutes or more without showing thermistor abnormality?

No

Replace the inverter P.C. board.

Yes

OK. (Cause is poor contact.)

MUZ-HE09/12/15/18NA

Thermistor	Symbol	Connector, Pin No.	Board
Defrost	RT61	Between CN641 pin1 and pin2	Inverter P.C. board
Discharge temperature	RT62	Between CN641 pin3 and pin4	
Fin temperature	RT64	Between CN642 pin1 and pin2	
Ambient temperature	RT65	Between CN643 pin1 and pin2	
Outdoor heat exchanger temperature	RT68	Between CN644 pin1 and pin3	

MUZ-HE24NA

Thermistor	Symbol	Connector, Pin No.	Board
Defrost	RT61	Between CN671 pin1 and pin2	Inverter P.C. board
Discharge temperature	RT62	Between CN671 pin3 and pin4	
Fin temperature	RT64	Between CN673 pin1 and pin2	
Ambient temperature	RT65	Between CN672 pin1 and pin2	
Outdoor heat exchanger temperature	RT68	Between CN671 pin5 and pin6	

H Check of R.V. coil

※ First of all, measure the resistance of R.V. coil to check if the coil is defective. Refer to 10-4.

※ In case CN721 (MUZ-HE09/12/15/18)/CN602 (MUZ-HE24) is disconnected or R.V. coil is open, voltage is generated between the terminal pins of the connector although no signal is being transmitted to R.V. coil. Check if CN721 (MUZ-HE09/12/15/18)/CN602 (MUZ-HE24) is connected.

Unit operates COOL mode even if it is set to HEAT mode.

Disconnect connector between the compressor and intelligent power module/power module ※1.
Turn ON the power supply and press EMERGENCY OPERATION switch twice (HEAT mode).

Is there 208/230 VAC between CN721 (MUZ-HE09/12/15/18)/CN602 (MUZ-HE24)① and ② on the inverter P.C. board 3 minutes after the power supply is turned ON?

No

Replace the inverter P.C. board.

Yes


Replace the 4-way valve.

※1


Intelligent power module: MUZ-HE24NA

Power module: Other models

Unit operates HEAT mode even if it is set to COOL mode.



① Check of outdoor fan motor



J Check of power supply

MUZ-HE09/12/15/18NA

※1

Intelligent power module: **MUZ-HE24NA**

Power module: **Other models**

Disconnect the connector (CN61) between compressor and intelligent power module/power module ※1.
Turn ON power supply and press EMERGENCY OPERATION switch.

Does the upper lamp of OPERATION INDICATOR lamp on the indoor unit light up?

No

Is there voltage 208/230 VAC between the indoor terminal block S1 and S2?

No

Replace the indoor electronic control P.C. board.

Yes

Is there bus-bar voltage 260-325 VDC between DB61 (+) and DB61 (-) on the inverter P.C. board? (Refer to 10-6.1.)

Yes

Does LED on the inverter P.C. board light up or flash? (Refer to 10-6.1.)

No

Replace the inverter P.C. board.

No


Check the electric parts in main circuit.

Rectify indoor/outdoor connecting wire.

Yes

Yes

If LED lights up, it is OK.
If LED flashes, refer to 10-3.



MUZ-HE24NA

Disconnect the connector between compressor and intelligent power module/power module ※1.
Turn ON power supply and press EMERGENCY OPERATION switch.

Does the upper lamp of OPERATION INDICATOR on the indoor unit light up?

No

Is there voltage 208/230 VAC between the indoor terminal block S1 and S2?

No

Replace the indoor electronic control P.C. board.

Yes

Is there bus-bar voltage 294 - 370 VDC between JP715 (+) and JP30 (-) on the inverter P.C. board? (Refer to 10-6.1.)

Yes

Does LED on the inverter P.C. board light up or flash? (Refer to 10-6.1.)

No

Replace the inverter P.C. board.

No


Check the electric parts in main circuit.

Rectify indoor/outdoor connecting wire.

Yes

Yes

If LED lights up, it is OK.
If LED flashes, refer to 10-3.





K Check of LEV (Expansion valve)

Turn ON the power supply.

<Preparation of the remote controller>

- ① While pressing both OPERATION SELECT button and TOO COOL button on the remote controller at the same time, press RESET button.
- ② First, release RESET button.
Hold down the other two buttons for another 3 seconds. Make sure that the indicators on the LCD screen shown in the right figure are all displayed. Then release the buttons.



※1. Regardless of normal or abnormal condition, a short beep is emitted once the signal is received.

Press OPERATE/STOP (ON/OFF) button of the remote controller (the set temperature is displayed) with the remote controller headed towards the indoor unit. ※1

Expansion valve operates in full-opening direction.

Do you hear the expansion valve "click, click....."?
Do you feel the expansion valve vibrate on touching it?

Yes → OK.

No

Is LEV coil properly fixed to the expansion valve?

No

Properly fix the LEV coil to the expansion valve.

Yes

Does the resistance of LEV coil have the characteristics? (Refer to 10-4.)

Yes

Measure each voltage between connector pins of CN724 on the inverter P.C. board.

1. Pin③(-) — Pin①(+)
2. Pin④(-) — Pin①(+)
3. Pin⑤(-) — Pin①(+)
4. Pin⑥(-) — Pin①(+)

Is there about 3 ~ 5 VAC between each?
NOTE: Measure the voltage by an analog tester.

No

Replace the inverter P.C. board.

Yes


Replace the expansion valve.

Replace the LEV coil.

NOTE: After check of LEV, do the undermentioned operations.


1. Turn OFF the power supply and turn ON it again.
2. Press RESET button on the remote controller.

Ⓐ Check of inverter P.C. board





M How to check miswiring and serial signal error


MUZ-HE09/12/15/18NA



MUZ-HE24NA



N Electromagnetic noise enters into TV sets or radios



Even if all of the above conditions are fulfilled, the electromagnetic noise may enter, depending on the electric field strength or the installation condition (combination of specific conditions such as antennas or wiring). Check the followings before asking for service.

1. Devices affected by the electromagnetic noise
TV sets, radios (FM/AM broadcast, shortwave)
2. Channel, frequency, broadcast station affected by the electromagnetic noise
3. Channel, frequency, broadcast station unaffected by the electromagnetic noise
4. Layout of:
indoor/outdoor unit of the air conditioner, indoor/outdoor wiring, grounding wire, antennas, wiring from antennas, receiver
5. Electric field intensity of the broadcast station affected by the electromagnetic noise
6. Presence or absence of amplifier such as booster
7. Operation condition of air conditioner when the electromagnetic noise enters in
 - 1) Turn OFF the power supply once, and then turn ON the power supply. In this situation, check for the electromagnetic noise.
 - 2) Within 3 minutes after turning ON the power supply, press OPERATE/STOP (ON/OFF) button on the remote controller for power ON, and check for the electromagnetic noise.
 - 3) After a short time (3 minutes later after turning ON), the outdoor unit starts running. During operation, check for the electromagnetic noise.
 - 4) Press OPERATE/STOP (ON/OFF) button on the remote controller for power OFF, when the outdoor unit stops but the indoor/outdoor communication still runs on. In this situation, check for the electromagnetic noise.


10-6. TEST POINT DIAGRAM AND VOLTAGE

1. Inverter P.C. board




MUZ-HE09NA

MUZ-HE12NA


MUZ-HE15NA






Defrost thermistor (RT61)
Ambient temperature thermistor (RT65)
Outdoor heat exchanger temperature thermistor (RT68)



MUZ-HE18NA



Defrost thermistor (RT61)
Ambient temperature thermistor (RT65)
Outdoor heat exchanger temperature thermistor (RT68)



MUZ-HE24NA

Fuse (F62)
T2.0AL250V

Fuse (F601)
T3.15AL250V

R.V. coil (CN602)
208/230 VAC

Jumper wire for
changing defrost
setting (JS)

Jumper wire for
pre-heat control
setting (JK)

Signal of out-
door fan motor
(CN931)

LED

Output to
drive outdoor
fan motor
(CN932)

Fuse (F901)
T3.15AL250V

Fuse (F880)
T3.15AL250V

Defrost thermistor
/RT61 (CN671)

Discharge temperature
thermistor/RT62
(CN671)

Outdoor heat exchanger
temperature thermistor
/RT68 (CN671)

Ambient temperature
thermistor/RT65
(CN672)

Fin temperature
thermistor/RT64
(CN673)




LEV connector (CN724)

JP715 (+)

Bus-bar voltage
294 - 370 VDC

JP30 (-)

Defrost thermistor (RT61)
Ambient temperature thermistor (RT65)
Outdoor heat exchanger temperature thermistor (RT68)



<"Terminal with locking mechanism" Detaching points>

The terminal which has the locking mechanism can be detached as shown below.



There are two types (refer to (1) and (2)) of the terminal with locking mechanism.

The terminal without locking mechanism can be detached by pulling it out.

Check the shape of the terminal before detaching.

(1) Slide the sleeve and check if there is a locking lever or not.




(2) The terminal with this connector has the locking mechanism.






11-1. MUZ-HE09NA MUZ-HE12NA MUZ-HE15NA

NOTE: Turn OFF power supply before disassembly.



OPERATING PROCEDURE	PHOTOS
1. Removing the cabinet (1) Remove the screw fixing the service panel. (2) Pull down the service panel and remove it. (3) Remove the screws fixing the conduit cover. (4) Remove the conduit cover. (5) Disconnect the power supply wire and indoor/outdoor connecting wire. (6) Remove the screws fixing the top panel. (7) Remove the top panel. (8) Remove the screws fixing the cabinet. (9) Remove the cabinet. (10) Remove the screws fixing the back panel. (11) Remove the back panel.	Photo 1 Photo 2

OPERATING PROCEDURE	PHOTOS
2. Removing the inverter assembly, inverter P.C. board (1) Remove the cabinet and panels. (Refer to 1.) (2) Disconnect the lead wire to the reactor and the following connectors: <Inverter P.C. board> CN641 (Defrost thermistor and discharge temperature thermistor) CN643 (Ambient temperature thermistor) CN644 (Outdoor heat exchanger temperature thermistor) CN721 (R.V. coil) CN724 (LEV) CN931, CN932 (Fan motor) (3) Remove the compressor connector (CN61). (4) Remove the screws fixing the heat sink support and the separator. (5) Remove the fixing screws of the terminal block support and the back panel. (6) Remove the inverter assembly. (7) Remove the screw of the ground wire and screw of the terminal block support. (8) Remove the heat sink support from the P.C. board support. (9) Remove the screw of the inverter P.C. board and remove the inverter P.C. board from the P.C. board support.	Photo 3 Screw of the heat sink support and the separator Screws of the terminal block support and the back panel  Photo 4 (Inverter assembly) Heat sink Hook of the P.C. board support Inverter P.C. board P.C. board support Screw of the terminal block support Terminal block support Screw of the ground wire Heat sink support Hook of the P.C. board support Screw of the P.C. board fixture 
3. Removing R.V. coil (1) Remove the cabinet and panels. (Refer to 1.) (2) Disconnect the following connectors: <Inverter P.C. board> CN721 (R.V. coil) (3) Remove the R.V. coil.	Photo 5 R.V. coil  Discharge temperature thermistor

OPERATING PROCEDURE	PHOTOS
4. Removing the discharge temperature thermistor, defrost thermistor, outdoor heat exchanger temperature thermistor and ambient temperature thermistor (1) Remove the cabinet and panels. (Refer to 1.) (2) Disconnect the lead wire to the reactor and the following connectors: <Inverter P.C. board> CN641 (Defrost thermistor and discharge temperature thermistor) CN643 (Ambient temperature thermistor) CN644 (Outdoor heat exchanger temperature thermistor) (3) Pull out the discharge temperature thermistor from its holder. (Photo 5) (4) Pull out the defrost thermistor from its holder. (5) Pull out the outdoor heat exchanger temperature thermistor from its holder. (6) Pull out the ambient temperature thermistor from its holder.	Photo 6 
5. Removing outdoor fan motor (1) Remove the cabinet and panels. (Refer to 1.) (2) Disconnect the following connectors: <Inverter P.C. board> CN931, CN932 (Fan motor) (3) Remove the propeller nut. (4) Remove the propeller. (5) Remove the screws fixing the fan motor. (6) Remove the fan motor.	Photo 7 Screws of the outdoor fan motor  Propeller Propeller nut
6. Removing the compressor and 4-way valve (1) Remove the cabinet and panels. (Refer to 1.) (2) Remove the inverter assembly. (Refer to 2.) (3) Recover gas from the refrigerant circuit. NOTE: Recover gas from the pipes until the pressure gauge shows 0 PSIG. (4) Detach the brazed part of the suction and the discharge pipes connected with compressor. (5) Remove the compressor nuts. (6) Remove the compressor. (7) Detach the brazed part of the pipes connected with 4-way valve.	Photo 8  Brazed parts of 4-way valve

11-2. MUZ-HE18NA

NOTE: Turn OFF power supply before disassembly.

OPERATING PROCEDURE	PHOTOS
1. Removing the cabinet (1) Remove the screws of the service panel. (2) Remove the screws of the top panel. (3) Remove the screw of the valve cover. (4) Remove the service panel. (5) Remove the top panel. (6) Remove the valve cover. (7) Disconnect the power supply and indoor/outdoor connecting wire. (8) Remove the screws of the cabinet. (9) Remove the cabinet. (10) Remove the screws of the back panel. (11) Remove the back panel.	Photo 1  Screw of the top panel Screws of the cabinet Screws of the back panel Screws of the cabinet Photo 2  Screws of the top panel Screws of the cabinet Screw of the service panel Screw of the valve cover Screws of the back panel

OPERATING PROCEDURE

2. Removing the inverter assembly, inverter P.C. board

- (1) Remove the cabinet and panels. (Refer to 1.)
- (2) Disconnect the lead wire to the reactor and the following connectors:
 <Inverter P.C. board>
 CN641 (Defrost thermistor and discharge temperature thermistor)
 CN643 (Ambient temperature thermistor)
 CN644 (Outdoor heat exchanger temperature thermistor)
 CN721 (R.V.coil)
 CN724 (LEV)
 CN931, CN932 (Fan motor)
- (3) Remove the compressor connector (CN61).
- (4) Remove the screws fixing the heat sink support and the separator.
- (5) Remove the fixing screws of the terminal block support and the back panel.
- (6) Remove the inverter assembly.
- (7) Remove the screw of the ground wire and screw of the terminal block support.
- (8) Remove the heat sink support from the P.C. board support.
- (9) Remove the screw of the inverter P.C. board and remove the inverter P.C. board from the P.C. board support.

PHOTOS

Photo 3






Photo 4 (Inverter assembly)






3. Removing R.V. coil

- (1) Remove the cabinet and panels. (Refer to 1.)
- (2) Disconnect the following connectors:
 <Inverter P.C. board>
 CN721 (R.V. coil)
- (3) Remove the R.V. coil.

Photo 5










OPERATING PROCEDURE	PHOTOS
4. Removing the discharge temperature thermistor, defrost thermistor, outdoor heat exchanger temperature thermistor and ambient temperature thermistor (1) Remove the cabinet and panels. (Refer to 1.) (2) Disconnect the lead wire to the reactor and the following connectors: <Inverter P.C. board> CN641 (Defrost thermistor and discharge temperature thermistor) CN643 (Ambient temperature thermistor) CN644 (Outdoor heat exchanger temperature thermistor) (3) Pull out the discharge temperature thermistor from its holder. (4) Pull out the defrost thermistor from its holder. (5) Pull out the outdoor heat exchanger temperature thermistor from its holder. (6) Pull out the ambient temperature thermistor from its holder.	Photo 6 
5. Removing outdoor fan motor (1) Remove the top panel, cabinet and service panel. (Refer to 1.) (2) Disconnect the following connectors: <Inverter P.C. board> CN931 and CN932 (Fan motor) (3) Remove the propeller. (4) Remove the screws fixing the fan motor. (5) Remove the fan motor.	Photo 7 
6. Removing the compressor and 4-way valve (1) Remove the top panel, cabinet and service panel. (Refer to 1.) (2) Remove the back panel. (Refer to 1.) (3) Remove the inverter assembly. (Refer to 2.) (4) Recover gas from the refrigerant circuit. NOTE: Recover gas from the pipes until the pressure gauge shows 0 PSIG. (5) Detach the brazed part of the suction and the discharge pipes connected with compressor. (6) Remove the compressor nuts. (7) Remove the compressor. (8) Detach the brazed parts of 4-way valve and pipes. (Photo 5)	Photo 8 

11-3. MUZ-HE24NA

NOTE: Turn OFF power supply before disassembly.

OPERATING PROCEDURE	PHOTOS
1. Removing the cabinet (1) Remove the screws of the service panel. (2) Remove the screws of the top panel. (3) Remove the screw of the valve cover. (4) Remove the service panel. (5) Remove the screws fixing the conduit cover. (6) Remove the conduit cover. (7) Remove the top panel. (8) Remove the valve cover. (9) Disconnect the power supply and indoor/outdoor connecting wire. (10) Remove the screws of the cabinet. (11) Remove the cabinet. (12) Remove the screws of the back panel. (13) Remove the back panel. Photo 2 	Photo 1  Photo 3 

OPERATING PROCEDURE	PHOTOS
2. Removing the inverter assembly, inverter P.C. board (1) Remove the cabinet and panels. (Refer to 1.) (2) Disconnect the lead wire to the reactor and the following connectors: <Inverter P.C. board> CN602 (R.V. coil) CN671 (Defrost thermistor, discharge temperature thermistor and outdoor heat exchanger temperature thermistor) CN672 (Ambient temperature thermistor) CN724 (LEV) CN931, CN932 (Fan motor) (3) Remove the compressor connector. (4) Remove the screws fixing the relay panel. (5) Remove the relay panel. (6) Remove the ground wires and the lead wires of the inverter P.C. board. (7) Remove the screw of the PB support. (8) Remove the inverter P.C. board from the relay panel.	Photo 4  Screw of the relay panel Screws of the PB support Ground wires Inverter P.C. board Screws of the PB support Screws of the relay panel
3. Removing R.V. coil (1) Remove the cabinet and panels. (Refer to 1.) (2) Disconnect the following connector: <Inverter P.C. board> CN602 (R.V. coil) (3) Remove the R.V. coil.	Photo 5  Screw of the R.V. coil Brazed parts of 4-way valve

OPERATING PROCEDURE

4. Removing the discharge temperature thermistor, defrost thermistor, outdoor heat exchanger temperature thermistor and ambient temperature thermistor

- (1) Remove the cabinet and panels. (Refer to 1.)
- (2) Disconnect the lead wire to the reactor and the following connectors:
<Inverter P.C. board>
CN671 (Defrost thermistor, discharge temperature thermistor and outdoor heat exchanger temperature thermistor)
CN672 (Ambient temperature thermistor)
- (3) Pull out the discharge temperature thermistor from its holder.
- (4) Pull out the defrost thermistor from its holder.
- (5) Pull out the outdoor heat exchanger temperature thermistor from its holder.
- (6) Pull out the ambient temperature thermistor from its holder.

5. Removing outdoor fan motor

- (1) Remove the top panel, cabinet and service panel. (Refer to 1.)
- (2) Disconnect the following connectors:
<Inverter P.C. board>
CN931 and CN932 (Fan motor)
- (3) Remove the propeller.
- (4) Remove the screws fixing the fan motor.
- (5) Remove the fan motor.

6. Removing the compressor and 4-way valve

- (1) Remove the top panel, cabinet and service panel. (Refer to 1.)
 - (2) Remove the back panel. (Refer to 1.)
 - (3) Remove the inverter assembly. (Refer to 2.)
 - (4) Recover gas from the refrigerant circuit.
- NOTE:** Recover gas from the pipes until the pressure gauge shows 0 PSIG.
- (5) Detach the brazed part of the suction and the discharge pipes connected with compressor.
 - (6) Remove the compressor nuts.
 - (7) Remove the compressor.
 - (8) Detach the brazed parts of 4-way valve and pipes. (Photo 5)

PHOTOS

Photo 6




Photo 7





Photo 8



mitsubishi electric corporation

HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN

© Copyright 2014 MITSUBISHI ELECTRIC CORPORATION
Distributed in Feb. 2014. No. OBH686
Made in Japan

New publication, effective Feb. 2014
Specifications are subject to change without notice.